



**NOTES**

1. INSTALL SADDLE INTO CORE DRILLED OPENING 45 DEGREES OFF VERTICAL CENTERLINE OF MAIN.
2. SUPPLY THE APPROPRIATE SIZE FOR THE TYPE OF PIPE AND SIZES OF MAIN AND LATERAL.
3. BACKFILL WITH AASHTO #8 AGGREGATE AROUND MAIN AND SADDLE. FOLLOW STANDARD TRENCH BEDDING AND BACKFILL DETAILS FOR EXISTING STREETS FOR REMAINING PIPE.
4. BOLTS TO BE TORQUED TO 5 FT-LBS EVENLY.
5. SADDLE TO BE SEALTITE BY GENECO OR EQUAL.

<p>TOWN OF MIDDLETOWN</p>	<p>STANDARD DETAIL</p>	<p>REVISIONS:</p>	<p>S-8</p>
	<p>SCH TO EXISTING</p>		
	<p>CLAY PIPE SEWER</p>		
	<p>MAIN-SADDLE METHOD</p>		
<p>APPROVED: _____</p> <p style="text-align: center; margin-left: 100px;">12/13/01</p> <p style="text-align: center; margin-left: 100px;">DATE</p>			